

2011 Nissan Xterra Factory Service Manual

Edition: August 2010 Revision: March 2012 Publication No. SM1E-1N50U1		QUICK REFERENCE INDEX		A B C D E F G H I J K L M N O P
NISSAN XTERRA MODEL N50 SERIES		A GENERAL INFORMATION	GI General Information	
		B ENGINE	EM Engine Mechanical	
			LU Engine Lubrication System	
			CO Engine Cooling System	
			EC Engine Control System	
			FL Fuel System	
			EX Exhaust System	
			STR Starting System	
			ACC Accelerator Control System	
		C HYBRID	HBC Hybrid Control System	
			HBB Hybrid Battery System	
		D TRANSMISSION & DRIVE-LINE	CL Clutch	
			TM Transaxle & Transmission	
			DLN Driveline	
			FAX Front Axle	
			RAX Rear Axle	
		E SUSPENSION	FSU Front Suspension	
			RSU Rear Suspension	
			SCS Suspension Control System	
			WT Road Wheels & Tires	
		F BRAKES	BR Brake System	
			PB Parking Brake System	
			BRC Brake Control System	
		G STEERING	ST Steering System	
			STC Steering Control System	
		H RESTRAINTS	SB Seat Belt	
			SBC Seat Belt Control System	
			SR SRS Airbag	
			SRC SRS Airbag Control System	
		I VENTILATION, HEATER & AIR CONDITIONER	VTL Ventilation System	
			HA Heater & Air Conditioning System	
			HAC Heater & Air Conditioning Control System	
		J BODY INTERIOR	INT Interior	
			IP Instrument Panel	
			SE Seat	
			ADP Autodrive Positioner System	
			AP Adjustable Pedals	
		K BODY EXTERIOR, DOORS, ROOF & VEHICLE SECURITY	DLK Door & Lock	
			SEC Security Control System	
			GW Glass & Window System	
			PWC Power Window Control System	
			RF Roof	
			EXT Exterior	
		L DRIVER CONTROLS	BRM Body Repair Manual	
			MIR Mirrors	
			EXL Exterior Lighting System	
			INL Interior Lighting System	
			VWV Wiper & Washer	
			DEF Defogger	
			HRN Horn	
		M ELECTRICAL & POWER CONTROL	PWO Power Outlet	
			BCS Body Control System	
			LAN LAN System	
			PCS Power Control System	
			CHG Charging System	
			PG Power Supply, Ground & Circuit Elements	
		N DRIVER INFORMATION & MULTIMEDIA	MW Meter, Warning Lamp & Indicator	
			WCS Warning Chime System	
			SN Sonar System	
			AV Audio, Visual & Navigation System	
		O CRUISE CONTROL	CCS Cruise Control System	
		P MAINTENANCE	MA Maintenance	

All rights reserved. No part of this Service Manual may be reproduced or stored in a retrieval system, or transmitted in any form, or by any means, electronic, mechanical, photo-copying, recording or otherwise, without the prior written permission of Nissan North America, Inc.

[DOWNLOAD HERE](#)

2011 NISSAN XTERRA FACTORY SERVICE MANUAL USED BY TECHNICIANS AT THE DEALERSHIPS TO MAINTAIN, SERVICE, DIAGNOSE AND REPAIR YOUR VEHICLE. COMPLETE STEP-BY-STEP INSTRUCTIONS, DIAGRAMS, ILLUSTRATIONS, WIRING SCHEMATICS, AND SPECIFICATIONS TO COMPLETELY REPAIR YOUR VEHICLE WITH EASE! YOU GET EVERYTHING YOU WILL EVER NEED THROUGH BOOKS TO FIND WHAT YOU NEED. PRINT ONLY THE PAGES

AND DIAGRAMS YOU REQUIRE. NO MORE GREASY PAGES OR TORN LOST PAPER MANUALS AGAIN. ALL PAGES ARE PRINTABLE, SO PRINT OFF WHAT YOU NEED & TAKE IT WITH YOU TO YOUR VEHICLE OR WORKSHOP. YOU CAN BLOW-UP IMAGES AND THEN PRINT OFF ENLARGED COPIES! FACTORY HIGHLY DETAILED REPAIR MANUALS, WITH COMPLETE INSTRUCTIONS AND ILLUSTRATIONS, WIRING SCHEMATICS AND DIAGRAMS TO COMPLETELY SERVICE AND REPAIR YOUR VEHICLE. QUICK REFERENCE INDEX A GENERAL INFORMATION GI General Information B ENGINE EM Engine Mechanical LU Engine Lubrication System CO Engine Cooling System EC Engine Control System FL Fuel System EX Exhaust System STR Starting System ACC Accelerator Control System C HYBRID HBC Hybrid Control System HBB Hybrid Battery System HBR Hybrid Brake System D TRANSMISSION & DRIVE- LINE CL Clutch System TM Transaxle & Transmission DLN Driveline FAX Front Axle RAX Rear Axle E SUSPENSION FSU Front Suspension RSU Rear Suspension SCS Suspension Control System WT Road Wheels & Tires F BRAKES BR Brake System PB Parking Brake System BRC Brake Control System G STEERING ST Steering System STC Steering Control System H RESTRAINTS SB Seat Belt SBC Seat Belt Control System SR SRS Airbag SRC SRS Airbag Control System I VENTILATION, HEATER & AIR CONDITIONER VTL Ventilation System HA Heater & Air Conditioning System HAC Heater & Air Conditioning Control System J BODY INTERIOR INT Interior IP Instrument Panel SE Seat ADP Automatic Drive Positioner K BODY EXTERIOR, DOORS, ROOF & VEHICLE SECURITY DLK Door & Lock SEC Security Control System GW Glass & Window System PWC Power Window Control System RF Roof EXT Exterior BRM Body Repair Manual L DRIVER CONTROLS MIR Mirrors EXL Exterior Lighting System INL Interior Lighting System WW Wiper & Washer DEF Defogger HRN Horn M ELECTRICAL & POWER CONTROL PWO Power Outlet BCS Body Control System LAN LAN System PCS Power Control System CHG Charging System PG Power Supply, Ground & Circuit Elements N DRIVER INFORMATION & MULTIMEDIA MWI Meter, Warning Lamp & Indicator WCS Warning Chime System SN Sonar System AV Audio, Visual & Navigation System O CRUISE CONTROL CCS Cruise Control System P MAINTENANCE MA Maintenance Format: PDF (Adobe Reader) Language: English Delivery: Download Compatibility: Any Windows or Mac (using Adobe Reader) Some bought files need to be extracted from zip or rar archive!

[DOWNLOAD HERE](#)

Similar manuals: