

Merrylock 3040 Sewing Machine Instruction Manual

TABLE OF CONTENTS

	Page
1. Principal Parts.....	5
2. Accessories.....	7
3. Needle Information.....	7
4. How to Open Looper Cover.....	8
5. Principal Parts Behind Looper Cover.....	8
6. Preparation prior to sewing.....	8
7. Preparation for threading.....	10
*Setting up the thread guide holder.....	10
*Anti-spill net.....	10
*Spool cap.....	10
8. How to Remove and Insert Needles.....	11
*Needle position.....	11
*To remove needle(s).....	11
*To insert needle(s).....	11
9. Threading the Machine.....	12
*Threading diagram.....	12
*Understanding the color code.....	12
*To thread the machine correctly.....	13
1) Threading the chain stitch looper (Brown).....	13
2) Threading the cover stitch needles.....	15
① Threading the cover stitch left needle (Orange).....	15
② Threading the cover stitch middle/chain stitch Needle(Blue).....	16
③ Threading the cover stitch right Needle(Green).....	18
10. How to Change Threads / Tie on Method.....	20
11. How to Adjust the Stitch length.....	21
12. How to Adjust the Presser Foot Pressure.....	21
13. Differential Feed.....	22
14. Selection of stitches.....	23
15. Handy Reference Chart.....	23
16. Suggested Tension Setting.....	24
1) Double chain stitch.....	24
17. How to Sew a Cover Stitch.....	26
18. Machine Maintenance.....	31
19. Snap-On Type Presser Foot.....	33
20. Troubleshooting Chart.....	34
21. Relationship between Cloth, Thread and Need.....	35
22. Specification.....	36

[DOWNLOAD HERE](#)

Merrylock 3040 Sewing Machine Instruction Manual

[DOWNLOAD HERE](#)

Similar manuals:

[Merrylock 2020 Overlocker Instruction Manual](#)

[Merrylock 740DS Overlocker Instruction Manual](#)

[Merrylock 3040 Sewing Machine Instruction Manual](#)

[Merrylock 2040 Sewing Machine Instruction Manual](#)