

Kenmore 385.16227300 Sewing Machine Instruction Manual

TABLE OF CONTENTS	
SECTION I. NAME OF PARTS	
Cabinets and Sewing Machine Tote Bag	2
Names of Parts	2
Available Accessories and Attachments	4
SECTION II. GETTING READY TO SEW	
Connecting Machine to Power Supply	6
Before Using Your Sewing Machine	6
For Your Safety	6
Polarized plug	6
Controlling Sewing Speed	6
Pressure Adjusting Lever	8
Presser Foot Lifter	8
Thread Cutter	8
Extension Table	8
• Detaching the table	8
• Attaching the table	8
• Accessory box	8
Changing Needle	10
To Remove and Attach the Foot Holder	10
• To remove	10
• To attach	10
Changing Presser Foot	10
• To remove	10
• To attach	10
Presser Foot Types	12
• A: Zigzag foot	12
• H: Straight stitch foot	12
• R: Automatic buttonhole foot	12
• E: Zipper foot	12
• G: Blind hem stitch foot	12
• F: Satin stitch foot	14
• C: Overedge foot	14
• B: Buttonhole foot (Option)	14
• Quilter	14
• 1/4" Seam foot	14
• Walking foot	14
Selecting Needle and Fabric	16
Bobbin Winding	20-24
• Horizontal spool pin	20
• Additional spool pin	20
• Bobbin winding	20
• Removing the hook cover plate	24
• Inserting the bobbin	24
Threading the Machine	26-28
• Threading the machine	26
• Needle threader	26
• Drawing up bobbin thread	28
Adjust the Needle Thread Tension for a Straight Stitch	28-30
• Correct tension	28
• Tension is too tight	28
• Tension is too loose	30
Adjust the Needle Thread Tension for a Zigzag Stitch	30
• Correct tension	30
• Tension is too tight	30
• Tension is too loose	30
Stitch Selector	32
Stitch Length Zones	32
Stitch Width Control	34
Stitch Length Control	34
Adjusting Stretch Stitch Balance	36
Reverse Stitch Control	36
SECTION III. STRAIGHT STITCH SEWING	
Straight Stitch	38
• Starting to sew	38
• Finishing sewing	38
Use the Seam Guides	38
Turn a Square Corner	38
Topstitching	40
Quilting	40
Using Walking Foot	42
Using 1/4" Seam Foot	42
Zipper Sewing	44-46
• To snap on the zipper foot	44
• Fabric preparation	44
• To sew	44-46
To Drop or Raise the Feed Dogs	48
Darning	48
SECTION IV. ZIGZAG STITCH SEWING	
Basic Zigzag	50
Satin Stitching	50
Monogramming	52
Applique	52
Bar Tacking	54
Embroidery	54
Button Sewing	56
Overcasting	56
SECTION V. UTILITY AND DECORATIVE STITCHES	
Blind Hem Stitch	58
• To sew	58
Lace Work	60
Multiple Zigzag Stitch	60
• Seam finishing	60
• Mending	60
Shell Stitch	62
Box Stitch	62
Fagoting Stitch	64
Two-point Shell Stitch	64
Two-point Box Stitch	64
Overedge Stitch	66
Decorative Stitch Patterns	66
Twin Needle Stitches (Option)	68
SECTION VI. STRETCH STITCHES	
Straight Stretch	70
Rick-rack Stretch	70
Overcast Stretch Stitching	72
• To sew	72
Smocking	72
• To sew	72
Serging	74
Elastic Stretch Stitch	74
Stretch Patching	74
Herring Bone Stretch	76
Decorative Stretch Patterns	76
SECTION VII. BUTTONHOLE	
Automatic Buttonhole	78-82
• Preparation for sewing	78
• To sew	78-80
• How to adjust buttonhole stitch density	82
Corded Buttonhole	84
Manual Buttonhole (Option)	86
• To sew	86
Automatic Buttonhole (Option)	88-94
• Buttonhole style and size	88
• To sew	90-94
• To adjust stitch density	94
SECTION VIII. CARE OF YOUR MACHINE	
Replacing the Light Bulb	96
Cleaning the Bobbin Holder	96
Cleaning the Shuttle Race and Feed Dogs	98
Oiling the Machine	98
Troubleshooting	100

[DOWNLOAD HERE](#)

Kenmore 385.16227300 Sewing Machine Instruction Manual

[DOWNLOAD HERE](#)

Similar manuals:

Machtkonstruktion Eines Schiedsrichters Im Sport Am Beispiel Basketball Erklärt Anhand Des Symbolischen Interaktionismus - Thomas Kaeckenmeister

Die Wegenutzung Nach Dem Hamburgischen Wegegesetz - Florian Käckenmester