

# Husqvarna Viking Designer II, Quilt Designer Service

## Manual

## Contents

|                                                                                                   |    |
|---------------------------------------------------------------------------------------------------|----|
| Directions for use                                                                                | 4  |
| ESD                                                                                               | 4  |
| Service tools                                                                                     | 5  |
| <b>SETTINGS</b>                                                                                   | 6  |
| 1. The play of the hook gear                                                                      | 7  |
| 2. Setting the hook in relation to the feeding eccentric (after feeding)                          | 8  |
| 3. Belt tension, arm/lower shaft belt                                                             | 9  |
| 4. Belt tension, motor belt                                                                       | 9  |
| 5. Setting the feeding unit sideways                                                              | 10 |
| 6. Basic setting - the step motor of the needle                                                   | 11 |
| 7. Setting of the needle in relation to the presser foot                                          | 13 |
| 8. The gap between the needle and the hook                                                        | 14 |
| 9. The timing of the hook in relation to the needle                                               | 15 |
| 10. The needle height                                                                             | 16 |
| 11. Presser foot parallelism to the feed dog                                                      | 17 |
| 12. Presser foot height to the stitch plate                                                       | 17 |
| 13. Setting the stitch plate (the hook cover) in relation to the needle in the feeding direction. | 18 |
| 14. The sideways setting of the stitch plate (the hook cover) in relation to the presser foot.    | 18 |
| 15. The height of the hook, ver. 1                                                                | 19 |
| 15. The height of the hook, ver. 2                                                                | 20 |
| 16. Pre-setting of the step motor for the side feeding                                            | 21 |
| 17. Setting the feeding mechanism sideways                                                        | 22 |
| 18. Feed dog height                                                                               | 23 |
| 19. Threading device                                                                              | 24 |
| 20. Stitch length balance basic setting                                                           | 25 |
| 21. Pre-setting the step motor of the feed dog                                                    | 26 |
| 22. Stitch length balance                                                                         | 27 |
| 23. Lower thread tension (thread tension of the bobbin case)                                      | 28 |
| 24. Upper thread tension - Position "Norm" - Designer I                                           | 29 |
| 24. Upper thread tension - Position "Norm" - Designer II and Quilt Designer                       | 30 |
| 25. Upper thread tension - Position "Embr/Dec" - Designer I                                       | 31 |
| 25. Upper thread tension - Position "Embr/Dec" - Designer II                                      | 32 |
| 25. Upper thread tension - Position "Decor" - Quilt Designer                                      | 33 |
| 26. Upper thread guard sensor                                                                     | 34 |
| 27. Setting the thread take-up spring                                                             | 35 |
| 28. Disconnection when winding the bobbin                                                         | 35 |
| 29. Pivot height                                                                                  | 36 |
| <b>SERVICE PROGRAM</b>                                                                            |    |
| Service program - Designer I                                                                      | 37 |
| Functions of the service menu 2 - Designer I - Sensor check                                       | 40 |
| Functions of the service menu 3 - Designer I - Upper thread tension                               | 41 |
| Calibration of the touch panel - Designer I                                                       | 42 |
| Update of the memory - Designer I                                                                 | 43 |
| Service program Designer II                                                                       | 44 |
| Functions of the service menu 2 - Designer II                                                     | 47 |
| Sensor check - Function of the Service menu 1                                                     | 47 |
| Functions of the service menu 3 - Designer II                                                     | 48 |
| Upper thread tension and Pivot position                                                           | 48 |
| Functions of the Service Menu 4 - Designer II                                                     | 48 |
| Log menu                                                                                          | 48 |
| Calibration of the touch panel - Designer II                                                      | 49 |
| Update of the memory - Designer II (Read & write unit)                                            | 50 |
| Service program for Quilt Designer                                                                | 51 |
| Function of the Service menu 1                                                                    | 52 |
| Functions of the service menu 2 - Sensor check                                                    | 54 |

[DOWNLOAD HERE](#)

[DOWNLOAD HERE](#)

Similar manuals:

[2006 Husqvarna TC TE SMR 250 400 450 510 Workshop Service Repair Manual DOWNLOAD](#)

[2006 Husqvarna WRCR125 Workshop Service Repair Manual DOWNLOAD](#)

[2002 Husqvarna WR CR 250 360 Workshop Service Repair Manual DOWNLOAD](#)

[2007 Husqvarna SM-TE 610IE Workshop Repair Manual DOWNLOAD](#)

[HUSQVARNA CHAINSAW 250PS DIGITAL WORKSHOP REPAIR MANUAL](#)

[HUSQVARNA CHAINSAW 33 DIGITAL WORKSHOP REPAIR MANUAL](#)

[HUSQVARNA CHAINSAW 385XP DIGITAL WORKSHOP REPAIR MANUAL](#)

[HUSQVARNA SC18 SOD CUTTER DIGITAL WORKSHOP REPAIR MANUAL](#)

[HUSQVARNA CHAINSAW 2100 DIGITAL WORKSHOP REPAIR MANUAL](#)

[HUSQVARNA CHAINSAW 335XPT DIGITAL WORKSHOP REPAIR MANUAL](#)

[HUSQVARNA CHAINSAW MODEL 181 DIGITAL WORKSHOP REPAIR MANUAL](#)

[HUSQVARNA ZTH RIDE ON MOWER DIGITAL WORKSHOP MANUAL](#)

[HUSQVARNA CHAINSAW MODEL 40 DIGITAL WORKSHOP REPAIR MANUAL](#)

[HUSQVARNA CHAINSAW 336 339XP DIGITAL WORKSHOP REPAIR MANUAL](#)

[HUSQVARNA CHAINSAW 394XP DIGITAL WORKSHOP MANUAL](#)

[HUSQVARNA 165R CLEARING SAW DIGITAL WORKSHOP REPAIR MANUAL](#)

[HUSQVARNA CR125 WR125 DIGITAL WORKSHOP REPAIR MANUAL 2011-2012](#)

[HUSQVARNA CHAINSAW 154 254 DIGITAL WORKSHOP REPAIR MANUAL](#)

[HUSQVARNA SM400 SM450R DIGITAL WORKSHOP REPAIR MANUAL 2001-2004](#)

[HUSQVARNA CHAINSAW 340 345 350 DIGITAL WORKSHOP REPAIR MANUAL](#)

[HUSQVARNA 250 450 ENGINE DIGITAL WORKSHOP REPAIR 2003](#)

[HUSQVARNA RIDER 11 RIDE ON MOWER DIGITAL WORKSHOP REPAIR MANUAL](#)

[HUSQVARNA CHAINSAW 42 42D 242 DIGITAL WORKSHOP REPAIR MANUAL](#)

[HUSQVARNA BDP MODELS 10A 21L DIGITAL WORKSHOP REPAIR MANUAL](#)

[HUSQVARNA CHAINSAW 357XP 359 DIGITAL WORKSHOP REPAIR MANUAL](#)

[HUSQVARNA CHAINSAW 340 345 346XP DIGITAL WORKSHOP REPAIR MANUAL](#)

[HUSQVARNA CHAINSAW 246 254XP 257 DIGITAL WORKSHOP REPAIR MANUAL](#)

[HUSQVARNA CHAINSAW 346XP 351 DIGITAL WORKSHOP REPAIR MANUAL](#)

[HUSQVARNA CHAINSAW 371XP XPG DIGITAL WORKSHOP REPAIR MANUAL](#)

[HUSQVARNA TC250 TC450 DIGITAL WORKSHOP REPAIR MANUAL 2001-2004](#)

[HUSQVARNA TE250 TE450 DIGITAL WORKSHOP REPAIR MANUAL 2001-2004](#)

[HUSQVARNA RIDER 16 RIDE ON MOWER DIGITAL WORKSHOP REPAIR MANUAL](#)

[HUSQVARNA CHAINSAW 334T 338XPT DIGITAL WORKSHOP REPAIR MANUAL](#)

[HUSQVARNA CHAINSAW 350 351 353 DIGITAL WORKSHOP REPAIR MANUAL](#)

[HUSQVARNA TRIMMER 23 26 32 LC L DIGITAL WORKSHOP REPAIR MANUAL](#)

[HUSQVARNA CHAINSAW 51 55 61 242XP DIGITAL WORKSHOP REPAIR MANUAL](#)

[HUSQVARNA RIDER 11 BIO RIDER ON MOWER DIGITAL WORKSHOP REPAIR MANUAL](#)

[HUSQVARNA RIDER 13H RIDE ON MOWER DIGITAL WORKSHOP REPAIR MANUAL](#)

[HUSQVARNA CHAINSAW 262XP 268 272XP DIGITAL WORKSHOP REPAIR MANUAL](#)

[HUSQVARNA RIDER 1200 RIDE ON MOWER DIGITAL WORKSHOP REPAIR MANUAL](#)

[HUSQVARNA CHAINSAW 268K 272K 272S DIGITAL WORKSHOP REPAIR MANUAL](#)

[HUSQVARNA RIDER 16H RIDE ON MOWER DIGITAL WORKSHOP REPAIR MANUAL](#)

[HUSQVARNA CHAINSAW 263 280 380 480 DIGITAL WORKSHOP REPAIR MANUAL](#)

[HUSQVARNA CHAINSAW 36 40 41 45 DIGITAL WORKSHOP REPAIR MANUAL](#)

[HUSQVARNA RIDER PRO 15 RIDE ON MOWER DIGITAL WORKSHOP REPAIR MANUAL](#)

[HUSQVARNA RIDER 14 PRO RIDE ON MOWER DIGITAL WORKSHOP REPAIR MANUAL](#)

[HUSQVARNA RIDER 11 13 RIDE ON MOWER DIGITAL WORKSHOP REPAIR MANUAL](#)

[HUSQVARNA CHAINSAW 362XP 365 372XP DIGITAL WORKSHOP REPAIR MANUAL](#)

[HUSQVARNA CHAINSAW 362XP 365 371XP DIGITAL WORKSHOP REPAIR MANUAL](#)

