

Lg Rd-jt-40 & Jt-41 , Projector Original Service Manual

LG RD-JT40/41 Service Manual



RD-JT40/RD-JT41 SERVICE MANUAL



Caution

Be sure to read this manual before servicing. To assure safety from fire, electric shock, injury, harmful radiation and materials, various measures are provided in this Acer DLP projector. Be sure to read cautionary items described in the manual to maintain safety before servicing.

Service Warning

1. When replace the lamp, to avoid burns to yor fingers. The lamp becomes too hot.
2. Nevr touch the lamp bulbwith a finger or anything else. Never drop it or give it a shock. They may cause bursting of the bulb.
3. This projector is provided with a high voltage circuit for the lamp. Do not touch the electric parts of power unit (main), when turn on the pojector.
4. Do not touch the exhaust fan, during operation.

Contents

1. Specifications.....	2
2. Spare Parts List	4
3. Shipping Cntents.....	5
4. Projector Dsrption.....	6
5. Rmote Control Desription.....	9
6. Insallation.....	11
7. Operation.....	13
8. Shutdown.....	21
9. Maintenance.....	22
10. Lamp Replacement.....	23
11. Trouble Shooting.....	25
12. Timing Char.....	33
13. DMD Image Secification.....	34
14. Electrical nterface Character.....	37
15. Final Assembly Alignent Procedure.....	39
16. Paking Description.....	44
17. Appearance Description.....	45
18. Dimension.....	47
19. Schematics.....	48
20. Assy Drawing.....	85

[DOWNLOAD HERE](#)

LG RD-JT40 & JT41 , Projector Original Service Manual PDF format suitable for Windows XP, Vista, 7 , 8 and Mac Fully Bookmarked PDF file Chassis & Electrical Wiring diagrams Most Complete Service Manual Available Numerous Illustrations Technical Diagnostic Procedures Disassembly & Installation Procedures Written by the Manufacturer Used by the Dealership Technicians You can print the specific pages you

need to accomplish the repairs required or print the whole manual

[DOWNLOAD HERE](#)

Similar manuals: