

Kenmore 385.16655100 Sewing Machine Instruction Manual

OPERATING INSTRUCTIONS

TABLE OF CONTENTS

SECTION I. NAME OF PARTS	2	Thread tension adjustment.....	52
Tote Bags	2	Thread tension dial.....	52
Locate and Identify the parts	2	Incorrect tension.....	52
Attaching the waste catcher	4	Incorrect tension.....	52
Storing the accessory holder	4	Incorrect tension.....	54
Standard accessories	4	Incorrect tension.....	54
Available Accessories and Attachments	6	Thread tension (3 threads).....	56
SECTION II. GETTING READY TO SEW	8	Correct tension	56
Plug in the machine and switch on the power	8	Thread tension adjustment.....	56
Operating Instructions	8	Thread tension dial.....	56
Foot control use	8	Incorrect tension.....	56
How to turn handwheel	10	Incorrect tension.....	56
Opening and closing the side cover	10	Incorrect tension.....	56
• To open	10	Narrow hem	58
• To close	10	Rolled hem	60
Opening and closing the looper cover	10	Picot edge	62
• To open	10	Turning corners	64
• To close	10	Outsider corners	64
For your safety	10	Inside corners	66
Positioning the telescoping thread guide bar	12	Edging curves	66
Attaching the spool cap and net	12	• Outside curves	66
Raising or lowering the presser foot	12	• Inside curves	66
Adjustment of stitch length	14	Overedging	68
Adjustment of differential feed ratio	14	Overlocking	70
How to adjust	14	Elastic (for wide elastic band)	72
Changing the needle	16	Elastic (for narrow elastic band)	74
• To attach the needle on the right	16	Lace application	76
• To attach the needle on the left	16	Decorative edge	78
Adjustment of foot pressure	16	Decorative flatlock (Topstitching).....	80
Removing the presser foot	18	Blind hem	82
Attaching the presser foot	18	Pintuck	84
To disengage the upper knife	18	Attaching stretch waistband	86
To engage the upper knife	18	Braiding	88
Adjustment of cutting width	20	Attach sleeve	90
Adjustment of needle plate setting knob	22	Flared skirt	92
(Changing to standard serging or rolled hemming)	22	Gathering	94
Standard serging	22	SECTION IV. CARE FOR MACHINE	96
Rolled hemming	22	Replacing the upper knife	96
Setting the lower looper pre-tension setting slider	24	To remove	96
Standard serging (STD.)	24	To attach	96
Rolled hemming(R.H.)	24	Cleaning upper knife area	96
Initial Set-Up	26	Replacing the light bulb	98
Rethreading a broken thread	28	For your safety	98
Rethreading the Serger	30-32	To remove	98
Threading the lower looper	30-32	To insert	98
How to thread woolly nylon / polyester thread	34	Cleaning the feed dogs	98
Threading the upper looper	36-38	Oiling the machine	100
To rethread the upper looper	38	Carrying the machine	100
Threading the right needle	40	SECTION V. PERFORMANCE	102
Threading the left needle	42		
3-thread serging	44		
Regular 3-thread serging: 1/8" (3.5 mm) width	44		
Wide 3-thread serging: 1/4" (5.7 mm) width	44		
SECTION III. LEARN THE STITCHES	46		
Starting to sew	46		
Finishing sewing	46		
Sewing continuously	46		
How to use guide lines	46		
Securing ends	48		
• At the beginning of the seam	48		
• Backstitching	48		
• At the end of the seam	48		
Thread and needle chart	50-51		
Thread tension (4 threads)	52		
Correct tension	52		

[DOWNLOAD HERE](#)

Kenmore 385.16655100 Sewing Machine Instruction Manual

[DOWNLOAD HERE](#)

Similar manuals:

Machtkonstruktion Eines Schiedsrichters Im Sport Am Beispiel Basketball Erklärt Anhand Des Symbolischen Interaktionismus - Thomas Kaeckenmeister

Die Wegenutzung Nach Dem Hamburgischen Wegegesetz - Florian Käckenmester