

Cat 988b Wheel Loader Parts Manual Volume 1



SEBP1388-08
February 1999

VOLUME I
Pages 1-566

Parts Manual



See "General Information"
for New Parts Manual
Features.

988B Wheel Loader

50W6041-99999 (Machine)
48W14354-99999 (Engine)
1JE1-99999 (Transmission)
2MA1-99999 (Transmission)
23T1-99999 (Torque Converter)

Powered By 3408 Engine

[DOWNLOAD HERE](#)

Caterpillar Parts Manual Volume 1 988B Wheel Loader

[DOWNLOAD HERE](#)

Similar manuals: