

# Mitsubishi Fuso Canter Service Manual 2012 Fe Fg

## **FE.FG**

### **SERVICE MANUAL**

#### **2012 Model**

#### **FOREWORD**

This Service Manual contains maintenance and repair methods for the Mitsubishi Fuso Truck FE, FG Series. Read this manual carefully as an aid in providing correct, efficient maintenance. Please note that the information and specifications contained within this manual may change without notice. This is due to product modifications and continued vehicle improvements that are made throughout the model years. Should you encounter any discrepancy in the information provided, please do not hesitate to contact your nearest Mitsubishi Fuso Dealer or Mitsubishi Fuso Truck of America, Inc.

MARCH 2011

#### **GROUP INDEX**

|                                   |     |
|-----------------------------------|-----|
| GENERAL .....                     | 00  |
| MAINTENANCE SCHEDULE .....        | 01  |
| ENGINE.....                       | 11  |
| LUBRICATION .....                 | 12  |
| FUEL AND ENGINE CONTROL.....      | 13  |
| COMMON RAIL SYSTEM.....           | 13E |
| COOLING.....                      | 14  |
| INTAKE AND EXHAUST .....          | 15  |
| EMISSION CONTROL .....            | 17  |
| BlueTec® SYSTEM .....             | 17E |
| CLUTCH.....                       | 21  |
| TRANSMISSION <DUONIC™> .....      | 22  |
| DUONIC™ .....                     | 22E |
| TRANSFER.....                     | 24  |
| PROPELLER SHAFT .....             | 25  |
| FRONT AXLE                        |     |
| <FE> .....                        | 26A |
| <FG> .....                        | 26B |
| REAR AXLE.....                    | 27  |
| WHEEL AND TIRE .....              | 31  |
| FRONT SUSPENSION .....            | 33  |
| REAR SUSPENSION.....              | 34  |
| BRAKE.....                        | 35  |
| ANTI-LOCK BRAKE SYSTEM (ABS) .... | 35E |
| PARKING BRAKE .....               | 36  |
| STEERING .....                    | 37  |
| BUMPER AND FRAME .....            | 41  |
| CAB.....                          | 42  |
| DOOR.....                         | 43  |
| EXTERIOR .....                    | 51  |
| INTERIOR .....                    | 52  |
| ELECTRICAL.....                   | 54  |
| HEATER, AIR-CONDITIONER           |     |
| AND VENTILATION.....              | 55  |
| FULL AUTOMATIC                    |     |
| AIR-CONDITIONER.....              | 55E |

[DOWNLOAD HERE](#)

Mitsubishi Fuso Canter Service Manual 2012 Chassis Type: FEC52S FEC72S FEC72W FEC92S  
FGB72S Engine Type: 4P10 4P10-T5 00 GENERAL 01 MAINTENANCE SHEDULE 11 ENGINE 12  
LUBRICATION 13 FUEL & ENGINE CONTROL 13E COMMON RAIL SYSTEM 14 COOLING 15 INTAKE  
& EXHAUST 17 EMISSION CONTROL 17E BLUETEC SYSTEM 21 CLUTCH 22 TRANSMISSION  
(DUONIC) 22E DUONIC 24 TRANSFER 25 PROPELLER SHAFT 26 FRONT AXLE (FE) 26 FRONT  
AXLE (FG) 27 REAR AXLE 31 WHEEL & TIRE 33 FRONT SUSPENSION 34 REAR SUSPENSION 35  
BRAKE 35E ANTI-LOCK BRAKE SYSTEM 36 PARKING BRAKE 37 STEERING 41 BUMPER AND

FRAME 42 CAB 43 DOOR 51 EXTERIOR 52 INTERIOR 54 ELECTRICAL 55 HEATER, AIR  
CONDITIONER AND VENTILATION 55E FULL AUTOMATIC AIR CONDITIONER PAGES 2664  
FORMAT: PDF, ZIP LANGUAGE: English Win95/98/ME/XP/vista/7/Linux/MAC We provide various  
Repair Manual, Service manual, Workshop Manual, for Cars, Trucks, Industrial Equipment, Heavy  
Equipment ...etc All in a pdf and software from various kinds of brand cars and motorcycles \* INSTANT  
DOWNLOAD \* NO SHIPPING COST \* NO NEED TO WAIT FOR A CD-ROM If you are looking for a  
specific manual & cant find it then contact our customer support team via the Contact Seller link with  
details of the required manual & we will do our absolute best to acquire it for you.

[DOWNLOAD HERE](#)

Similar manuals:

[mitsubishi fuso canter fe fg 2012 2013 workshop manual](#)