

Kenmore 385.17624 Sewing Machine Instruction Manual

TABLE OF CONTENTS

SECTION I. NAME OF PARTS		III. STRAIGHT STITCH SEWING (continued)	
Portable Case or Cabinet	2	Quilting	40
Names of Parts	2	Zipper Sewing	42 - 44
Available Accessories and Attachments	4	• To snap on the zipper foot	42
SECTION II. GETTING READY TO SEW		• Fabric preparation	42
Connecting Machine to Power Supply	6	• To sew	42
For Your Safety	6	To Drop or Raise the Feed Dogs	46
Operating Instructions	6	Darning	46
Controlling Sewing Speed	6	SECTION IV. ZIGZAG STITCHES	
Pressure Adjusting Lever	8	Basic Zigzag	48
Presser Foot Lifter	8	Satin Stitch	48
Thread Cutter	8	Monogramming	50
Extension Table	8	Applique	50
Accessory Box	8	Bar Tacking	52
Changing Needle	10	Embroidery	52
To Remove and Attach the Foot Holder	10	Button Sewing	54
Changing Presser Feet	10	Overcasting Stitch	54
Presser Foot Types	12	SECTION V. UTILITY STITCHES AND	
• A: Zigzag foot	12	DECORATIVE STITCHES	
• H: Straight stitch foot	12	Blind Hem Stitch	56
• J: Sliding buttonhole foot	12	• To sew	56
• E: Zipper foot	12	• Changing needle position	56
• F: Satin stitch foot	12	Lace Work	58
• Automatic buttonhole foot	14	Multiple Zigzag Stitch	58
• G: Blind hem stitch foot	14	Shell Stitch	60
• Quilter	14	Box Stitch	60
Selecting Needle and Thread	16	Fagoting Stitch	62
Bobbin Winding	20-24	Two-point Shell Stitch	62
• Horizontal spool pin	20	Two-point Box Stitch	62
• Additional spool pin	20	Overedge Stitch	64
• Bobbin winding	22	Decorative Stitch of Geometric Patterns	64
• Removing the hook cover plate	24	SECTION VI. STRETCH STITCHES	
• Inserting the bobbin	24	Straight Stretch	66
Threading the machine	26	Rick-rack Stretch	66
• Threading the Machine	26	Overcast Stretch Stitching	68
• Drawing up bobbin thread	26	• To sew	68
Adjust the Needle Thread Tension for Straight		Smocking	68
Stitch	28	Serging	70
• Correct tension	28	Elastic Stretch Stitch	70
• Tension is too tight	28	Stretch Patching	70
• Tension is too loose	28	Herring Bone Stretch	72
Adjust the Needle Thread Tension for Zigzag		Decorative Stretch Patterns	72
Stitch	30	SECTION VII. BUTTONHOLE AND TWIN	
• Correct tension	30	NEEDLE STITCHES	
• Tension is too tight	30	Manual Buttonhole	74-78
• Tension is too loose	30	• To sew	74
Stitch Selector	32	How to Adjust Buttonhole Stitch Balance	78
Stitch Width Control	34	Automatic Buttonhole	80-86
Stitch Length Control	34	• Buttonhole style and size	80
Adjusting Stretch Stitch Balance	36	• To sew	82
Reverse Stitch Control	36	• To adjust stitch density	86
SECTION III. STRAIGHT STITCH SEWING		Twin Needle Stitches	88
Straight Stitch	38	SECTION VIII. CARE OF YOUR MACHINE	
• Starting to sew	38	Replacing the Light Bulb	90
• Finishing sewing	38	Cleaning the Bobbin Holder	90
Use the Seam Guides	38	Cleaning the Shuttle Race and Feed Dogs	92
Turn a Square Corner	38	Oiling the Machine	92
Use the Quilter Guide	38	Troubleshooting	94
Topstitching	40		

VI

[DOWNLOAD HERE](#)

Kenmore 385.17624 Sewing Machine Instruction Manual

[DOWNLOAD HERE](#)

Similar manuals:

[Machtkonstruktion Eines Schiedsrichters Im Sport Am Beispiel Basketball Erklärt Anhand Des Symbolischen Interaktionismus - Thomas Kaeckenmeister](#)

[Die Wegenutzung Nach Dem Hamburgischen Wegegesetz - Florian Käckenmester](#)