

Kenmore 385.16528000 Sewing Machine Instruction Manual

TABLE OF CONTENTS

SECTION I. NAME OF PARTS		SECTION III. STRAIGHT STITCH SEWING	
Cabinets and Tote Bags	2	(CONTINUED)	
Names of Parts	2	• To snap on the zipper foot	42
Available Accessories and Attachments	4	• Fabric preparation	42
SECTION II. GETTING READY TO SEW		• To sew	42-44
Connecting Machine to Power Supply	6	To Drop or Raise the Feed Dogs	46
For Your Safety	6	Darning	46
Operating Instructions	6	SECTION IV. ZIGZAG STITCHES	
Controlling Sewing Speed	6	Basic Zigzag	48
Pressure Adjusting Lever	8	Satin Stitch	48
Presser Foot Lifter	8	Monogramming	50
Thread Cutter	8	Applique	50
Extension Table	8	Bar Tacking	52
• Detaching the Table	8	Embroidery	52
• Attaching the Table	8	Button Sewing	54
• Accessory Box	8	Overcasting Stitch	54
Changing Needle	10	SECTION V. UTILITY STITCHES AND	
To Remove and Attach the Foot Holder	10	DECORATIVE STITCHES	
• To remove	10	Blind Hem Stitch	56
• To attach	10	• To sew	56
Changing Presser Foot	10	• Changing needle position	56
• To remove	10	Lace Work	58
• To attach	10	Multiple Zigzag Stitch	58
Presser Foot Types	12	Seam Finishing	58
• A: Zigzag foot	12	Mending	58
• H: Straight stitch foot	12	Shell Stitch	60
• R: Automatic buttonhole foot	12	Box Stitch	60
• E: Zipper foot	12	Fagoting Stitch	62
• C: Overedge foot	12	Two-point Shell Stitch	62
• F: Satin stitch foot	14	Two-point Box Stitch	62
• B: Buttonhole foot	14	Overedge Stitch	64
• G: Blind hem stitch foot	14	Decorative Stitch of Geometric Patterns	64
• Buttonhole foot (Option)	14	Twin Needle Stitches (Option)	66
• Quilter	14	SECTION VI. STRETCH STITCHES	
Selecting Needle and Fabric	16	Straight Stretch	68
Bobbin Winding	20-24	Rick-rack Stretch	68
• Horizontal spool pin	20	Overcast Stretch Stitching	70
• Additional spool pin	20	• To sew	70
• Bobbin winding	22	Smocking	70
• Removing the hook cover plate	24	• To sew	70
• Inserting the bobbin	24	Serging	72
Threading the Machine	26-28	Elastic Stretch Stitch	72
• Threading the machine	26	Stretch Patching	72
• Needle threader	26	Herring Bone Stretch	74
• Drawing up bobbin thread	28	Decorative Stretch Patterns	74
Adjust the Needle Thread Tension for Straight Stitch	28-30	SECTION VII. BUTTONHOLE	
• Correct tension	28	Automatic Buttonhole	76-80
• Tension is too tight	28	• Preparation for sewing	76
• Tension is too loose	30	• To sew	76-80
Adjust the Needle Thread Tension for Zigzag Stitch	30	• How to adjust buttonhole stitch density	80
• Correct tension	30	Corded Buttonhole	82
• Tension is too tight	30	Manual Buttonhole	84
• Tension is too loose	30	• To sew	84
Stitch Selector	32	Automatic Buttonhole (Option)	86-92
Stitch Width Control	34	• Buttonhole style and size	86
Stitch Length Control	34	• To sew	88
Adjusting Stretch Stitch Balance	36	• To adjust stitch density	92
Reverse Stitch Control	36	SECTION VIII. CARE OF YOUR MACHINE	
SECTION III. STRAIGHT STITCH SEWING		Replacing the Light Bulb	94
Straight Stitch	38	Cleaning the Bobbin Holder	94
• Starting to sew	38	Cleaning the Shuttle Race and Feed Dogs	96
• Finishing sewing	38	Oiling the Machine	96
Use the Seam Guides	38	Troubleshooting	98
Turn a Square Corner	38		
Use the Quilter Guide	40		
Topstitching	40		
Quilting	40		
Zipper Sewing	42-44		

[DOWNLOAD HERE](#)

Kenmore 385.16528000 Sewing Machine Instruction Manual

[DOWNLOAD HERE](#)

Similar manuals:

[Machtkonstruktion Eines Schiedsrichters Im Sport Am Beispiel Basketball Erklärt Anhand Des Symbolischen Interaktionismus - Thomas Kaeckenmeister](#)

[Die Wegenutzung Nach Dem Hamburgischen Wegegesetz - Florian Käckenmester](#)